




IT Tosaerba con conducente a bordo seduto - MANUALE DI ISTRUZIONI
ATTENZIONE: prima di usare la macchina, leggere attentamente il presente libretto.

DE Aufsitzmäher (Rasenmäher mit Fahrersitz mit sitzendem Benutzer)
GEBRAUCHSANWEISUNG




ACHTUNG: Vor Inbetriebnahme des Gerätes die Bedienungsanleitung aufmerksam lesen.





EN Ride-on lawnmower with seated operator - OPERATOR'S MANUAL
WARNING: read thoroughly the instruction booklet before using the machine.

FR Tondeuse à gazon à conducteur assis - MANUEL D'UTILISATION
ATTENTION: lire attentivement le manuel avant d'utiliser cette machine.



NL Grasmaaier met zittende bediener - GEBRUIKERSHANDLEIDING
LET OP: vooraleer de machine te gebruiken, dient men deze handleiding aandachtig te lezen.

ITALIANO - Istruzioni Originali	IT
БЪЛГАРСКИ - Инструкция за експлоатация	BG
BOSANSKI - Prijevod originalnih uputa	BS
ČESKY - Překlad původního návodu k používání	CS
DANSK - Oversættelse af den originale brugsanvisning	DA
DEUTSCH - Übersetzung der Originalbetriebsanleitung	DE
ΕΛΛΗΝΙΚΑ - Μετάφραση των πρωτοτύπων οδηγιών	EL
ENGLISH - Translation of the original instruction	EN
ESPAÑOL - Traducción del Manual Original	ES
EESTI - Algupärase kasutusjuhendi tõlge	ET
SUOMI - Alkuperäisten ohjeiden käännös	FI
FRANÇAIS - Traduction de la notice originale	FR
HRVATSKI - Prijevod originalnih uputa	HR
MAGYAR - Eredeti használati utasítás fordítása	HU
LIETUVIŠKAI - Originalių instrukcijų vertimas	LT
LATVIEŠU - Instrukciju tulkojums no oriģināl valodas	LV
МАКЕДОНСКИ - Превод на оригиналните упатства	MK
NEDERLANDS - Vertaling van de oorspronkelijke gebruiksaanwijzing	NL
NORSK - Oversettelse av den originale bruksanvisningen	NO
POLSKI - Tłumaczenie instrukcji oryginalnej	PL
PORTUGUÊS - Tradução do manual original	PT
ROMÂN - Traducerea manualului fabricantului	RO
РУССКИЙ - Перевод оригинальных инструкций	RU
SLOVENSKY - Preklad pôvodného návodu na použitie	SK
SLOVENŠČINA - Prevod izvirnih navodil	SL
SRPSKI - Prevod originalnih uputstva	SR
SVENSKA - Översättning av bruksanvisning i original	SV
TÜRKÇE - Orijinal Talimatların Tercümesi	TR







3.1**3.2****3.3****3.4**


3.5




3.6














3.6


















3.7











[1]	DATI TECNICI		MJ 66 Series
[2]	Potenza nominale *	kW	2,6 ÷ 3,6
[3]	Giri al minuto *	min ⁻¹	2450 ± 100
[4]	Impianto elettrico	V	12
[5]	Pneumatici anteriori		11 x 4,00-4" (13 x 5,00-6")
[6]	Pneumatici posteriori		13 x 5,00-6" (15 x 5,50-6")
[7]	Pressione gonfiaggio anteriore 11 x 4,00-4" 13 x 5,00-6"	bar bar	1,5 1,5
[8]	Pressione gonfiaggio posteriore 13 x 5,00-6" 15 x 5,50-6"	bar bar	1,5 1,0
[9]	Raggio minimo di erba non tagliata	cm	77,5
[10]	Altezza di taglio (11 x 4,00-4" / 13 x 5,00-6") (13 x 5,00-6" / 15 x 5,50-6")	cm	3 ÷ 6,4 3 ÷ 7,6
[11]	Larghezza di taglio	cm	66
[12]	Capacità del sacco di raccolta	l	140
[13]	Trasmissione meccanica Velocità di avanzamento (indicativa) a 3000 min ⁻¹ (11 x 4,00-4" / 13 x 5,00-6") (13 x 5,00-6" / 15 x 5,50-6")	km/h km/h	1,4 - 5,5 1,5 - 6,2
[14]	Trasmissione idrostatica Velocità di avanzamento (indicativa) a 3000 min ⁻¹ (11 x 4,00-4" / 13 x 5,00-6") (13 x 5,00-6" / 15 x 5,50-6")	km/h km/h	0 - 5,6 0 - 6,2
[15]	Limite di velocità con catene da neve (se accessorio previsto)	km/h	-
[16]	Dimensioni		
[17]	Lunghezza con sacco (lunghezza senza sacco)	mm	1825 (1480)
[18]	Larghezza (11 x 4,00-4" / 13 x 5,00-6") (13 x 5,00-6" / 15 x 5,50-6")	mm mm	718 722
[19]	Altezza (11 x 4,00-4" / 13 x 5,00-6") (13 x 5,00-6" / 15 x 5,50-6")	mm mm	1011 1047
[20]	Codice dispositivo di taglio		184109505/0
[21]	Capacità del serbatoio carburante	litri	4
[22]	Livello di pressione acustica	dB(A)	87
[23]	Incertezza di misura	dB(A)	0,89
[24]	Livello di potenza acustica misurato	dB(A)	98
[23]	Incertezza di misura	dB(A)	0,54
[25]	Livello di potenza acustica garantito	dB(A)	98
[26]	Livello di vibrazioni al posto di guida	m/s ²	2,94
[23]	Incertezza di misura	m/s ²	1,91
[27]	Livello di vibrazioni al volante	m/s ²	7,76
[23]	Incertezza di misura	m/s ²	2,16
[40]	ACCESSORI		
[41]	Kit "mulching"		✓
[42]	Carica batteria di mantenimento		O
[43]	Telo di copertura		✓

* Per il dato specifico, fare riferimento a quanto indicato nell'etichetta di identificazione della macchina.

O = Opzionale.

[1] BG - ТЕХНИЧЕСКИ ДАННИ [2] Номинална мощност * [3] Обороти в минута (*) [4] Електрическа система [5] Предни гуми [6] Задни гуми [7] Налигана предно напompване [8] Налигана задно напompване [9] Минимален радиус на неподрязана трева [10] Височина на косене [11] Ширина на косене [12] Вместимост на торбата за събиране на трева [13] Механична трансмисия - Скорост на напреждане (индикативна) - 3000 min⁻¹ [14] Хидростатична трансмисия - Скорост на напреждане (индикативна) - 3000 min⁻¹ [15] Граница на скоростта с верига за сняг (ако тази принадлежност е предвидена) [16] Размери [17] Дължина с торбата за събиране на трева (дължина без торбата за събиране на трева) [18] Ширина [19] Височина [20] Нод на инструмента за рязане [21] Вместимост на резервоара за гориво [22] Ниво на звуково налягане [23] Несигурност на измерване [24] Измерено ниво на акустична мощност [25] Гарантирано ниво на акустична мощност [26] Ниво на вибрации в мястото за управление [27] Ниво на вибрации на волана [40] АКСЕСОАРИ [41] Набор за "mulching" [42] Зарядно устройство за поддръжане [43] Покривен брезент * За специфични данни, вижте посоченото на идентификационния етикет на машината. O = Опционално	[1] BS - TEHNIČKI PODACI [2] Nazivna snaga (*) [3] Obrtaji u minuti (*) [4] Električna instalacija [5] Prednje gume [6] Zadnje gume [7] Pritisak vazduha u prednjim gumama [8] Pritisak vazduha u zadnjim gumama [9] Minimalan radijus nepokošene trave [10] Visina košenja [11] Širina košenja [12] Kapacitet vreće za skupljanje trave [13] Mehanički prijenos [14] Brzina kretanja (orijentaciono) na 3000 min⁻¹ [15] Hidrostatički prijenos [16] Brzina kretanja (orijentaciono) na 3000 min⁻¹ [17] Ograničenje brzine s lancima za snijeg (ako su oni predviđena dodatna oprema) [18] Dimenzije [19] Dužina s vrećom (dužina bez vreće) [20] Širina [21] Visina [22] Šifra rezne glave [23] Kapacitet spremnika goriva [24] Razina zvučnog pritiska [25] Mjerna nesigurnost [26] Izmjerena razina zvučne snage [27] Garantirana razina zvučne snage [28] Razina vibracija na mjestu vozača [29] Razina vibracija na volanu [40] DODATNA OPREMA [41] Komplet za malčiranje [42] Punjač akumulatora za održavanje [43] Pokrovna cerada * Za specifični podatke, pogledajte što je navedeno na identifikacionoj naljepnici mašine. O = Opcija	[1] CS - TECHNICKÉ PARAMETRY [2] Jmenovitý výkon (*) [3] Otáčky za minutu (*) [4] Elektroinstalace [5] Přední pneumatiky [6] Zadní pneumatiky [7] Tlak huštění předních pneumatik [8] Tlak huštění zadních pneumatik [9] Minimální poloměr neposečené trávy [10] Výška sekání [11] Šířka sekání [12] Kapacita sběrného koše [13] Mechanická převodovka Rychlost jezdce (přibližná) při 3000 min⁻¹ [14] Hydrostatická převodovka Rychlost jezdce (přibližná) při 3000 min⁻¹ [15] Mezní rychlost se sněhovými řetězy (pokud se jedná o určené příslušenství) [16] Rozměry [17] Délka s košem (Délka bez koše) [18] Šířka [19] Výška [20] Kód sekacího zařízení [21] Kapacita palivového nádržky [22] Úroveň akustického tlaku [23] Nepečnost měření [24] Úroveň naměřeného akustického výkonu [25] Úroveň zaručeného akustického výkonu [26] Úroveň vibrací na místě řidiče [27] Úroveň vibrací na volantu [40] PŘÍSLUŠENSTVÍ [41] Sada pro mulčování [42] Udržovací nabíječka akumulátoru [43] Krycí plachta * Ohledně uvedeného údaje vycházejte z hodnoty uvedené na identifikačním štítku stroje. O = Volitelné příslušenství.
[1] DA - TEKNISKE DATA [2] Nominel effekt (*) [3] Omdrejninger pr. minut (*) [4] Elektrisk anlæg [5] Forhjulsdæk [6] Baghjulsdæk [7] Pumpetryk for forådk [8] Pumpetryk for bagådk [9] Minimumsradius af ikke klippet græs [10] Klippehøjde [11] Klippebredde [12] Størrelse på opsamlingspose [13] Mekanisk transmission - Fremdriftshastighed (vejledende) ved 3000 min⁻¹ [14] Hydrostatisk transmission - Fremdriftshastighed (vejledende) ved 3000 min⁻¹ [15] Hastighedsgrænse med snekedder (hvis disse er forudset) [16] Mål [17] Længde med opsamlingspose (længde uden pose) [18] Bredde [19] Højde [20] Skæreanordningens varenr [21] Brændstofstankens kapacitet [22] Lydtryksniveau [23] Måleusikkerhed [24] Målt lydeffektniveau [25] Garanteret lydeffektniveau [26] Vibrationsniveau på førersædet [27] Vibrationsniveau ved rattet [40] TILBEHØR [41] Sæt til "mulching" [42] Udladningsbatterilader [43] Presenning * For disse data henvises til hvad der er angivet på maskinens identifikationsmærkat. O = Tilbehør.	[1] DE - TECHNISCHE DATEN [2] Nennleistung (*) [3] Umdrehungen pro Minute (*) [4] Elektrische Anlage [5] Reifen Vorderräder [6] Reifen Hinterräder [7] Reifendruck vorne [8] Reifendruck hinten [9] Mindestradius nicht geschnittenes Gras [10] Schnitthöhe [11] Schnittbreite [12] Fassungsvermögen der Grasfangeinrichtung [13] Mechanischer Antrieb - Vorschubgeschwindigkeit (Richtwert) bei 3000 min⁻¹ [14] Hydrostatischer Antrieb - Vorschubgeschwindigkeit (Richtwert) bei 3000 min⁻¹ [15] Geschwindigkeitsgrenze mit Schneeketten (falls als Zubehör vorgesehen) [16] Abmessungen [17] Länge mit Grasfangeinrichtung (Länge ohne Grasfangeinrichtung) [18] Breite [19] Höhe [20] Code Schneidwerkzeug [21] Inhalt des Kraftstofftanks [22] Schalldruckpegel [23] Messungenaugkeit [24] Gemessener Schalleistungspegel [25] Garantierter Schalleistungspegel [26] Vibrationspegel am Fahrersitz [27] Vibrationspegel am Lenkrad [40] ANBAUGERÄTE [41] "Mulching"-kit [42] Batterieladegerät [43] Abdeckung * Für die genaue Angabe nehmen Sie bitte auf das Typenschild der Maschine Bezug. O = Optional.	[1] EL - ΤΕΧΝΙΚΑ ΧΑΡΑΚΤΗΡΙΣΤΙΚΑ [2] Ονομαστική ισχύς (*) [3] Στροφές ανά λεπτό (*) [4] Ηλεκτρικό σύστημα [5] Εμπρόσθια ελαστικά [6] Πίσω ελαστικά [7] Πίεση εμπρόσθιων ελαστικών [8] Πίεση πίσω ελαστικών [9] Ελάχιστη активη μη κομμένου χόρτου [10] Ύψος κοπής [11] Πλάτος κοπής [12] Χωρητικότητα του κάδου περισυλλογής [13] Μηχανικό σύστημα μετάδοσης Ταχύτητα κίνησης (ενδεικτική) στις 3000 σ.α.λ. [14] Υδροστατικό σύστημα μετάδοσης Ταχύτητα κίνησης (ενδεικτική) στις 3000 σ.α.λ. [15] Όριο ταχύτητας με αλυσίδες χιονιού (αν προβλέπεται ως εξοπλισμό) [16] Διαστάσεις [17] Μήκος με κάδο (μήκος χωρίς κάδο) [18] Πλάτος [19] Ύψος [20] Κωδικός συστήματος κοπής [21] Χωρητικότητα του ντεπόζιτου καυσίμου [22] Στάθμη ακουστικής πίεσης [23] Αβεβαιότητα μέτρησης [24] Μετρομένη στάθμη ακουστικής ισχύος [25] Εγγυημένη στάθμη ακουστικής ισχύος [26] Επίπεδο κραδασμών στη θέση του οδηγού [27] Επίπεδο κραδασμών στο τιμόνι [40] ΕΞΑΡΤΗΜΑΤΑ [41] Σετ "mulching" [42] Φορτιστής συντηρησης μπαταρίας [43] Καλυμμα προστασίας * Για το συγκεκριμένο στοιχείο, ελέγξτε τα όσα αναγράφονται στην ετικέτα προσδιορισμού του μηχανήματος. O = Προαιρετικά.

[1] EN - TECHNICAL DATA [2] Nominal power (*) [3] RPM (*) [4] Electrical system [5] Front tyres [6] Rear tyres [7] Front tyre pressure [8] Rear tyre pressure [9] Minimum radius of uncut grass [10] Cutting height [11] Cutting width [12] Grass catcher capacity [13] Mechanical transmission Forward speed (approximate) at 3000 min⁻¹ [14] Hydrostatic transmission Forward speed (approximate) at 3000 min⁻¹ [15] Speed limit with snow chains (if available) [16] Dimensions [17] Length with grass catcher (length without grass catcher) [18] Width [19] Height [20] Cutting means code [21] Fuel tank capacity [22] Acoustic pressure level [23] Measurement uncertainty [24] Measured acoustic power level [25] Guaranteed acoustic power level [26] Operator position vibration level [27] Steering wheel vibration level [40] ATTACHMENTS [41] "Mulching" kit [42] Maintenance battery charger [43] Cloth cover * Please refer to the data indicated on the machine's identification plate for the exact figure. O = Optional.	[1] ES - DATOS TÉCNICOS [2] Potencia nominal (*) [3] Revoluciones por minuto (*) [4] Instalación eléctrica [5] Neumáticos anteriores [6] Neumáticos posteriores [7] Presión neumático anterior [8] Presión neumático posterior [9] Radio mínimo de hierba no cortada [10] Altura de corte [11] Anchura de corte [12] Capacidad de la bolsa de recolección [13] Transmisión mecánica Velocidad de avance (indicativa) a 3000 min-1 [14] Transmisión hidrostática Velocidad de avance (indicativa) a 3000 min-1 [15] Límite de velocidad con cadenas de nieve (si estuviera previsto el accesorio) [16] Dimensiones [17] Longitud con bolsa (longitud sin bolsa) [18] Anchura [19] Altura [20] Código dispositivo de corte [21] Capacidad del depósito carburante [22] Nivel de presión acústica [23] Incertidumbre de medida [24] Nivel de potencia acústica medido [25] Nivel de potencia acústica garantizado [26] Nivel de vibraciones en el puesto de conductor [27] Nivel de vibraciones al volante [40] ACCESORIOS [41] Kit para "mulching" [42] Cargador de batería de mantenimiento [43] Lona de cubierta * Para el dato específico, hacer referencia a lo indicado en la etiqueta de identificación de la máquina. O = Opción	[1] ET - TEHNILISED ANDMED [2] Nominaalvõimsus (*) [3] Pöörded minutis (*) [4] Elektrisüsteem [5] Eesmised rehvid [6] Tagumised rehvid [7] Pumpamise rõhk ees [8] Pumpamise rõhk taga [9] Lõikamata rohu minimaalne raadius [10] Lõikekõrgus [11] Lõikelaius [12] Kogumiskorvi maht [13] Mehaaniline jõuülekanne Edasilükumise kiirus (ligikaudne) 3000 min-1 [14] Hüdrostaatiline jõuülekanne Edasilükumise kiirus (ligikaudne) 3000 min-1 [15] Kiiruspiirang lumekettidega (kui on ettenähtud lisaseade) [16] Mõõtmised [17] Pikkus korviga (pikkus ilma korvita) [18] Laius [19] Kõrgus [20] Lõikeseadme kood [21] Kütusepaagi maht [22] Helirõhu tase [23] Mõõtemääramatus [24] Mõõdetud müravõimsuse tase [25] Garanteeritud müravõimsuse tase [26] Vibratsioonitase juhiistmel [27] Vibratsioonide tase roolis [40] LISASEADMED [41] „Multsimis“ komplekt [42] Hooldus akulaadija [43] Katterieie * Konkreetse info jaoks viidata masina identifitseerimisetiketil märgitule. O = Lisad.
[1] FI - TEKNISET TIEDOT [2] Nimellisteho (*) [3] Kierrosta minuutissa (*) [4] Sähkölaitteisto [5] Eturenkaat [6] Takarenkaat [7] Eturenkaiden täyttöpaine [8] Takarenkaiden täyttöpaine [9] Leikkaamattoman ruohon minimisäde [10] Leikkuukorkeus [11] Leikkuuleveys [12] Kerusäkin tilavuus [13] Mekaaninen voimansiirto Etenemisnopeus (suuntaa-antava) 3000 min⁻¹ [14] Hydrostaattinen voimansiirto Etenemisnopeus (suuntaa-antava) 3000 min⁻¹ [15] Nopeusrajoitus lumiketjuilla (jos kuuluu lisävarusteisiin) [16] Mitat [17] Pituus säkin kanssa (pituus ilman säkkiä) [18] Leveys [19] Korkeus [20] Leikkuuvälineen koodi [21] Polttoainesäiliön tilavuus [22] Akustisen paineen taso [23] Mittauksen epävarmuus [24] Mittattu äänitehotaso [25] Taattu äänitehotaso [26] Tärinätaso kuljettajan paikalla [27] Tärinätasoa ohjauspyörässä [40] LISÄVARUSTEET [41] Sippuamisarusteet [42] Ylläpitoakkulaturi [43] Suojakangas • Määrättyä arvoa varten, viittaa laitteen tunnuslaatassa annettuihin tietoihin. O = Valinnainen	[1] FR - CARACTÉRISTIQUES TECHNIQUES [2] Puissance nominale (*) [3] Tours par minute (*) [4] Installation électrique [5] Pneus avant [6] Pneus arrière [7] Pression de gonflage avant [8] Pression de gonflage arrière [9] Rayon minimal de l'herbe non taillée [10] Hauteur de coupe [11] Largeur de coupe [12] Capacité du bac de ramassage [13] Transmission mécanique Vitesse d'avancement (indicative) à 3000 min⁻¹ [14] Transmission hydrostatique Vitesse d'avancement (indicative) à 3000 min⁻¹ [15] Limite de vitesse avec chaînes à neige (si accessoire prévu) [16] Dimensions [17] Longueur avec sac (longueur sans sac) [18] Largeur [19] Hauteur [20] Code organe de coupe [21] Capacité du réservoir de carburant [22] Niveau de pression acoustique [23] Incertitude de mesure [24] Niveau de puissance acoustique mesuré [25] Niveau de puissance acoustique garantie [26] Niveau de vibration au poste de conduite [27] Niveau de vibration au volant [40] EQUIPEMENTS [41] Kit pour "mulching" [42] Chargeur de batterie [43] Housse de protection • Pour la valeur spécifique, se référer à ce qui est indiqué sur la plaque signalétique de la machine. O = En option.	[1] HR - TEHNIČKI PODACI [2] Nazivna snaga (*) [3] Broj okretaja u minuti (*) [4] Električni sustav [5] Prednje gume [6] Stražnje gume [7] Tiak zraka u prednjim gumama [8] Tiak zraka u stražnjim gumama [9] Minimalni promjer nepokošene trave [10] Visina košnje [11] Širina košnje [12] Kapacitet košare za sakupljanje trave [13] Mehanički prijenos Brzina napredovanja (indikativno) pri 3.000 min-1 [14] Hidrostatski prijenos Brzina napredovanja (indikativno) pri 3.000 min-1 [15] Ograničenje brzine s lancima za snijeg (ako se radi o predviđenom dijelu dodatne opreme) [16] Dimenzije [17] Dužina s košarom (dužina bez košare) [18] Širina [19] Visina [20] Šifra noža [21] Zapremnina spremnika goriva [22] Razina zvučnog tlaka [23] Mjerna nesigurnost [24] Izmjerena razina zvučne snage [25] Zajamčena razina zvučne snage [26] Razina vibracija na vozačkom mjestu [27] Razina vibracija na upravljaču [40] DODATNA OPREMA [41] Komplet za "malčiranje" [42] Punjač baterija za održavanje [43] Zaštitna cerada • Specifični podatak pogledajte na identifikacijskoj etiketi stroja. O = Opcija.

[1] HU - MŰSZAKI ADATOK [2] Névleges teljesítmény (*) [3] Percenkénti fordulatszám (*) [4] Elektromos rendszer [5] Elülös gumibroncsok [6] Hátsó gumibroncsok [7] Elülös abroncsok légnyomása [8] Hátsó abroncsok légnyomása [9] Nem levágott fű minimális sugara [10] Nyírási magasság [11] Munkaszélesség [12] A gyújtózsák térfogata [13] Mechanikus erőátvitel Haladási sebesség (hőzzávetőlegesen) 3000 ford./perces fordulatszám [14] Hidrosztatikus erőátvitel Haladási sebesség (hőzzávetőlegesen) 3000 ford./perces fordulatszám [15] Sebességhorlát hőláncsal (ha tartozék) [16] Méretek [17] Hosszúság zsákkal (hosszúság zsák nélkül) [18] Szélesség [19] Magasság [20] Vágóegység kódszáma [21] Üzemanyagtartály kapacitása [22] Hangnyomásszint [23] Mérési bizonytalanság [24] Mért zajteljesítmény szint. [25] Garantált zajteljesítmény szint [26] A vezetőállásnál mért vibrációs szint [27] A kormánynál mért vibrációs szint [40] TARTOZÉKOK [41] "Mulcsoló készlet" [42] Fenntartó akkumulátortöltő [43] Takaró ponyva * A pontos adatot lásd a gép azonosító adatlábláján. O = Opció	[1] LT - TECHNINIAI DUOMENYS [2] Vardinė galia (*) [3] Apsisukimai per minutę (*) [4] Elektros instaliacija [5] Priekinės padangos [6] Užpakalinės padangos [7] Priekinių padangų oro slėgis [8] Užpakalinių padangų oro slėgis [9] Mažiausias nenupjautos žolės spindulys [10] Pjovimo aukštis [11] Pjovimo plotis [12] Surinkimo maišo talpa [13] Mechaninė transmisija Eligos greitis (apytikslis) per 3000 min-1 [14] Hidrostatinė transmisija Eligos greitis (apytikslis) per 3000 min-1 [15] Greičio riba su sniego grandinėmis (jei šis priedas numatytas) [16] Matmenys [17] Ilgis su maišu (ilgis be maišo) [18] Plotis [19] Aukštis [20] Pjovimo įtaiso kodas [21] Alyvos bako talpa [22] Garso slėgio lygis [23] Matavimo paklaida [24] Išmatuotas garso galios lygis [25] Garantuotas garso galios lygis [26] Vibracijų lygis, sėdynė [27] Vibracijų lygis, vairas [40] PRIEDAI [41] Rinkinys mulčiavimui [42] Akumuliatoriaus palaikymo įrenginys [43] Apsangalis * Konkretūs specifiniai duomenys yra pateikti įrenginio identifikavimo etiketėje. O = Pasirenkamas	[1] LV - TEHNISKIE DATI [2] Nominālā jauda (*) [3] Apgriezienu minūtē (*) [4] Elektroiekārta [5] Priekšējās riepas [6] Aizmugurējās riepas [7] Priekšējo riepu spiediens [8] Aizmugurējo riepu spiediens [9] Minimālais nenopļautās zāles rādiuss (zāles diametrs) no kreisās puses [10] Pļaušanas augstums [11] Pļaušanas platums [12] Savākšanas maisa tilpums [13] Mehāniskā transmisija Kustības ātrums (aptuvens) pie 3000 min-1 [14] Hidrostatiskā transmisija Kustības ātrums (aptuvens) pie 3000 min-1 [15] Ātruma ierobežojums sniega ķēžu izmantošanas gadījumā (ja šis piederums ir paredzēts) [16] Izmēri [17] Garums ar maisu (garums bez maisa) [18] Platums [19] Augstums [20] Griežējierīces kods [21] Degvielas ivertnes tilpums [22] Skaņas spiediena līmenis [23] Mērījumu kļūda [24] Izmērītais skaņas intensitātes līmenis [25] Garantētais skaņas intensitātes līmenis [26] Vibrāciju līmenis vadītāja vietā [27] Stūres vibrāciju līmenis [40] PIEDERUMI [41] Mulčēšanas komplekts [42] Akumulatoru atbalsta lādētājs [43] Pārvalks * Precīza vērtība ir norādīta mašīnas identifikācijas datu plāksnītē. O = Opcionāli
[1] МК - ТЕХНИЧНИ ПОДАТОЦИ [2] Номинална моќност (*) [3] Вртежи во минута (*) [4] Електрична инсталација [5] Предни пневматици [6] Задни пневматици [7] Притисок за полнење напред [8] Притисок за полнење назад [9] Минимален радиус на некосена трева [10] Висина на косење [11] Ширина на косење [12] Монтирање на вреќата за собирање [13] Механички пренос Брзина на движење (индикативна) до 3000 мин-1 [14] Хидростатички пренос Брзина на движење (индикативна) до 3000 мин-1 [15] Ограничување на брзината со синцири за снег (ако дополнителната опрема е предвидена) [16] Димензии [17] Должина со вреќата (должина без вреќата) [18] Ширина [19] Висина [20] Нод на уредот со сечивото [21] Напациет на резервоарот за гориво [22] Ниво на акустичен притисок [23] Отстапување од мерената [24] Измерено ниво на акустична моќност [25] Гарантирано ниво на акустична моќност [26] Ниво на вибрации на местото за управување [27] Ниво на вибрации на воланот [40] ДОПОЛНИТЕЛНА ОПРЕМА [41] Ноплет за „мелене“ [42] Полнач за акумулаторот со издржливорс [43] Платно за покривање * За одреден податок, проверете дали истиот е посочен на етикетата за идентификација на машината. O = По избор.	[1] NL - TECHNISCHE GEGEVENS [2] Nominaal vermogen (*) [3] Omwentelingen per minuut [4] Elektrische installatie [5] Voorbanden [6] Achterbanden [7] Bandenspanning vooraan [8] Bandenspanning achteraan [9] Minimum straal ongemaaide gras [10] Maaihoogte [11] Maai breedte [12] Vermogen van de opvangzak [13] Mechanische aandrijving (Indicatieve) voortbewegingssnelheid bij 3000 min-1 [14] Hydrostatische aandrijving (Indicatieve) voortbewegingssnelheid bij 3000 min-1 [15] Snelheidslimiet met sneeuwkettingen (indien dit toebehoort voorzien is) [16] Afmetingen [17] Lengte met zak (lengte zonder zak) [18] Breedte [19] Hoogte [20] Code snij-inrichting [21] Vermogen van het brandstofreservoir [22] Niveau geluidsdruk [23] Meetonzekerheid [24] Gemeten akoestisch vermogen [25] Gewaarborgd akoestisch vermogen [26] Niveau trillingen op de bestuurdersplaats [27] Niveau trillingen aan het stuur [40] TOEBEHOREN [41] Kit voor "mulching" [42] Batterij-oplader voor behoud [43] Afdekzeil * Voor het specifiek gegeven, verwijst men naar wat aangegeven is op het identificatielabel van de machine. O = Optie.	[1] NO - TEKNISKE DATA [2] Nominell effekt (*) [3] Omdreininger pr. minutt (*) [4] Elektrisk system [5] Fordekk [6] Bakdekk [7] Lufttrykk foran [8] Lufttrykk bak [9] Minste radius til ikke klippet gress) [10] Klippehøyde [11] Klippebredde [12] Oppsamlerens volum [13] Mekanisk transmisjon Fremdriftshastighet (ca.) ved 3 000 o/min. [14] Hydrostatisk transmisjon Fremdriftshastighet (ca.) ved 3 000 o/min. [15] Hastighetsgrense med snøkettinger (hvis finnes) [16] Mål [17] Lengde med oppsamlar (lengde uten oppsamlar) [18] Bredd [19] Høyde [20] Artikkelnummer for klippeinnretning [21] Drivstofflankens volum [22] Lydtrykknivå [23] Måleusikkerhet [24] Målt lydeffektivit [25] Garantert lydeffektivit [26] Vibrasjonsnivå ved førerplassen [27] Vibrasjonsnivå ved rattet [40] TILBEHØR [41] Mulching-sett [42] Batterilader [43] Presenning * For spesifik informasjon, se referansen på maskinens identifikasjonsetikkett. O = Ekstrautstyr

[1] PL - DANE TECHNICZNE [2] Moc znamionowa (*) [3] Liczba obrotów na minutę (*) [4] Instalacja elektryczna [5] Koła przednie [6] Koła tylne [7] Ciśnienie powietrza kół przednich [8] Ciśnienie powietrza kół tylnych [9] Minimalny promień nieskoszonej trawy [10] Wysokość koszenia [11] Szerokość koszenia [12] Pojemność pojemnika na trawę [13] Napęd mechaniczny Szybkość postępu (przybliżona) przy 3000 min-1 [14] Napęd hydrostatyczny Szybkość postępu (przybliżona) przy 3000 min-1 [15] Limit prędkości z łańcuchami (jeżeli przewidziane) [16] Wymiary [17] Długość z pojemnikiem (długość bez pojemnika) [18] Szerokość [19] Wysokość [20] Kod agregatu tnącego [21] Pojemność zbiornika paliwa [22] Poziom ciśnienia akustycznego [23] Błąd pomiaru [24] Poziom mocy akustycznej zmierzony [25] Gwarantowany poziom mocy akustycznej [26] Poziom drgań na stanowisku kierowcy [27] Poziom drgań na kierownicy [40] AKCESORIA [41] Zestaw mulczujący [42] Ładowarka akumulatora [43] Pokrowiec * W celu uzyskania konkretnych danych, należy się odnieść do wskazań zamieszczonych na tabliczce identyfikacyjnej maszyny. O = Opcjonalnie	[1] PT - DADOS TÉCNICOS [2] Potência nominal (*) [3] Rotações por minuto (*) [4] Instalação elétrica [5] Pneus dianteiros [6] Pneus traseiros [7] Pressão dos pneus dianteiros [8] Pressão dos pneus traseiros [9] Raio mínimo da relva não cortada [10] Altura de corte [11] Largura de corte [12] Capacidade do saco de recolha [13] Transmissão mecânica Velocidade de avanço (indicativa) a 3000 min-1 [14] Transmissão hidrostática Velocidade de avanço (indicativa) a 3000 min-1 [15] Limite de velocidade com correntes de neve (se o acessório for previsto) [16] Dimensões [17] Comprimento com saco (comprimento sem saco) [18] Largura [19] Altura [20] Código dispositivo de corte [21] Capacidade do tanque de combustível [22] Nível de pressão acústica [23] Incerteza de medição [24] Nível de potência acústica medido [25] Nível de potência acústica garantido [26] Nível de vibrações no local de condução [27] Nível de vibrações no volante [40] ACESSÓRIOS [41] Kit para "mulching" [42] Carregador de baterias de manutenção [43] Lona de cobertura * Para o dado específico, consulte a etiqueta de identificação da máquina. O = Opcional	[1] RO - DATE TEHNICE [2] Putere nominală (*) [3] Rotatii pe minut (*) [4] Instalație electrică [5] Pneuri față [6] Pneuri spate [7] Presiune roți față [8] Presiune roți spate [9] Raza minimă de iarăș netăiată [10] Înălțime de tăiere [11] Lățime de tăiere [12] Capacitatea sacului de colectare [13] Transmisie mecanică - Viteza de avans (indicativă) la 3000 min-1 [14] Transmisie hidrostatică - Viteză de avans (indicativă) la 3000 min-1 [15] Limită de viteză cu lanțuri de zăpadă (dacă acest accesoriu este prevăzut) [16] Dimensiuni [17] Lungime cu sac (lungime fără sac) [18] Lățime [19] Înălțime [20] Codul dispozitivului de tăiere [21] Capacitate rezervor carburant [22] Nivel de presiune acustică [23] Nesiguranță în măsurare [24] Nivel de putere acustică măsurat [25] Nivel de putere acustică garantat [26] Nivel de vibrații la locul conducătorului [27] Nivel de vibrații la volan [40] ACCESORII [41] Kit pentru „mulching” [42] Încărcător de baterie de întreținere [43] Prelată pentru acoperire * Pentru informația specifică, consultați datele de pe eticheta de identificare a mașinii. O = Opțional.
[1] RU - ТЕХНИЧЕСКИЕ ХАРАКТЕРИСТИКИ [2] Номинальная мощность (*) [3] Число оборотов в минуту (*) [4] Электропроводка [5] Передние шины [6] Задние шины [7] Давление в передних шинах [8] Давление в задних шинах [9] Минимальный радиус нескосенной травы [10] Высота скашиваемой травы [11] Ширина скашивания [12] Вместимость контейнера для сбора травы [13] Механическая трансмиссия - Скорость передвижения (ориентировочная) при 3000 мин-1 [14] Гидростатическая трансмиссия - Скорость передвижения (ориентировочная) при 3000 мин-1 [15] Предел скорости с цепями противоскольжения (если предусмотрено это дополнительное оборудование) [16] Габариты [17] Длина с контейнером (длина без контейнера) [18] Ширина [19] Высота [20] Код режущего приспособления [21] Объем топливного бака [22] Уровень звукового давления [23] Погрешность измерения [24] Измеренный уровень звуковой мощности [25] Гарантируемый уровень звуковой мощности [26] Уровень вибрации на месте водителя [27] Уровень вибрации на руле [40] ДОПОЛНИТЕЛЬНОЕ ОБОРУДОВАНИЕ [41] Комплект для мульчирования [42] Поддерживающее зарядное устройство [43] Защитный чехол * Точное значение см. на идентификационном ярлыке машины. O = Опция.	[1] SK - TECHNICKÉ PARAMETRE [2] Menovitý výkon (*) [3] Otáčky za minutu (*) [4] Elektroinštalácia [5] Predné pneumatiky [6] Zadné pneumatiky [7] Tlak hustenia predných pneumatík [8] Tlak hustenia zadných pneumatík [9] Minimálny akčný rádius otáčania [10] Výška kosenia [11] Šírka orezovania [12] Kapacita zberného koša [13] Mechanická prevodovka - Rýchlosť pohybu (približná) pri 3000 min-1 [14] Hydrostatická prevodovka - Rýchlosť pohybu (približná) pri 3000 min-1 [15] Hraničná rýchlosť so snehovými refazami (ak sa jedná o určené príslušenstvo) [16] Rozmery [17] Dĺžka s košom (dĺžka bez koša) [18] Šírka [19] Výška [20] Kód kosiaceho zariadenia [21] Kapacita palivovej nádržky [22] Úroveň akustického tlaku [23] Nepresnosť merania [24] Úroveň nameraného akustického výkonu [25] Úroveň zaručeného akustického výkonu [26] Úroveň vibrácií na mieste vodiča [27] Úroveň vibrácií na volante [40] PRÍSLUŠENSTVO [41] Súprava pre mulčovanie [42] Udrživacia nabíjačka akumulátora [43] Krycia plachta * Ohľadne uvedeného parametra vychádzajte z hodnoty uvedenej na identifikačnom štítku stroja. O = Voliteľné príslušenstvo	[1] SL - TEHNIČNI PODATKI [2] Nazivna moč (*) [3] Vrtljaji na minuto (*) [4] Električna napeljava [5] Prednje pnevmatike [6] Zadnje pnevmatike [7] Tlak v prednjih pnevmatikah [8] Tlak v zadnjih pnevmatikah [9] Najmanjše področje nepokošene trave [10] Višina košnje [11] Širina reza [12] Kapaciteta zbiralne košare [13] Mehanski menjalnik - Hitrost vožnje (približna) pri 3000 min-1 [14] Hidrostatični menjalnik - Hitrost vožnje (približna) pri 3000 min-1 [15] Omejitve hitrosti ob montiranih snežnih verigah (če so predvidene kot oprema) [16] Dimenzije [17] Džirna s košom (džirna bez koša) [18] Širina [19] Višina [20] Šifra rezalne naprave [21] Prostornina rezervoarja za gorivo [22] Raven zvočnega tlaka [23] Merilna negotovost [24] Izmerjena raven zvočne moči [25] Zajamčena raven zvočne moči [26] Stopnja vibracij na vozniškem sedežu [27] Nivo vibracij na volanu [40] DODATNA OPREMA [41] Komplet za mulčenje [42] Polnilnik akumulatorja za vzdrževanje [43] Prekrivno platno * Za specifični podatek glej identifikacijsko nalepko stroja. O = Opcijsko.

[1] **SR - TEHNIČKI PODACI**

- [2] Nazivna snaga (*)
[3] Obrtaj u minuti (*)
[4] Električna instalacija
[5] Prednje gume
[6] Zadnje gume
[7] Pritisak vazduha u prednjim gumama
[8] Pritisak vazduha u zadnjim gumama
[9] Minimalni poluprečnik nepokošene trave
[10] Visina košenja
[11] Širina košenja
[12] Kapacitet vreće za skupljanje trave
[13] Mehanički prenos
Brzina kretanja (orijentaciono) na 3000 min⁻¹
[14] Hidrostatički prenos
Brzina kretanja (orijentaciono) na 3000 min⁻¹
[15] Ograničenje brzine s lancima za sneg
(ukoliko su oni predviđeni kao dodatna oprema)
[16] Dimenzije
[17] Dužina s vrećom (dužina bez vreće)
[18] Širina
[19] Visina
[20] Šifra rezne glave
[21] Kapacitet rezervoara goriva
[22] Nivo zvučnog pritiska
[23] Merna nesigurnost
[24] Izmereni nivo zvučne snage
[25] Garantovani nivo zvučne snage
[26] Nivo vibracija na mestu vozača
[27] Nivo vibracija na volanu
[40] **DODATNA OPREMA**
[41] Komplet za malčiranje
[42] Punjač akumulatora za održavanje
[43] Pokrovna cerada

• Za specifični podatak, pogledajte podatke navedene na identifikacijskoj nalepnici mašine.
O = Opcija.

[1] **SV - TEKNISKA SPECIFIKATIONER**

- [2] Nominell effekt (*)
[3] Varv i minuten (*)
[4] Elanläggning
[5] Framdäck
[6] Backdäck
[7] Däcktryck fram
[8] Däcktryck bak
[9] Minimiradie på oklippt gräs
[10] Klipphöjd
[11] Klippbredd
[12] Uppsamlingspåsens kapacitet
[13] Mekanisk transm ission
Körhastighet (indikativ) vid 3 000 min⁻¹
[14] Hydrostatisk transmission
Körhastighet (indikativ) vid 3 000 min⁻¹
[15] Hastighetsgräns med snökedjor
(om tillbehör förutses)
[16] Dimensioner
[17] Längd med påse (längd utan påse)
[18] Bredd
[19] Höjd
[20] Skärenhetens kod
[21] Bränsletankens kapacitet
[22] Ljudtrycksnivå
[23] Trivel med mått
[24] Uppmått ljudeffektnivå
[25] Garanterad ljudeffektnivå
[26] Vibrationsnivå på förarplatsen
[27] Vibrationsnivå på ratten
[40] **TILLBEHÖR**
[41] Sats för "mulching"
[42] Batteriladdare för utjämningsladdning
[43] Presenning

* För specifik information, se uppgifterna på maskinens märklåt.
O = Tillval.

[1] **TR - TEKNİK VERİLER**

- [2] Nominal güç (*)
[3] Dakikadaki devir sayısı (*)
[4] Elektrik tesisi
[5] Ön tekerlekler
[6] Arka tekerlekler
[7] Ön şişirme basıncı
[8] Arka şişirme basıncı
[9] Minimum kesilmemiş çim yarıçap
[10] Kesim yüksekliği
[11] Kesim genişliği
[12] Toplama sepeti kapasitesi
[13] Mekanik transmisyon
3000 dak⁻¹ de ilerleme hızı (yaklaşık)
[14] Hidrostatik transmisyon
3000 dak⁻¹ de ilerleme hızı (yaklaşık)
[15] Kar zincirleri ile (aksesuar öngörülüyor ise) hız limiti
[16] Ebatlar
[17] Sepeti uzunluk (sepetsiz uzunluk)
[18] Genişlik
[19] Yükseklik
[20] Kesim düzeni kodu
[21] Yakıt deposu kapasitesi
[22] Ses basınç seviyesi
[23] Ölçü belirsizliği
[24] Ölçülen ses gücü seviyesi
[25] Garanti edilen ses gücü seviyesi
[26] Sürücü mahallinde titreşim seviyesi
[27] Direksiyonda titreşim seviyesi
[40] **AKSESUARLAR**
[41] "Malçlama" kiti
[42] Koruma batarya şarjörü
[43] Kaplama kılıfı

* Spesifik değer için, makine belirleme etiketinde belirtilenleri referans alın.
O = İsteğe bağlı.



For information on the engine and the battery, read the relevant owner manuals.

TABLE OF CONTENTS

1. SAFETY REGULATIONS	1
2. GETTING TO KNOW THE MACHINE	4
3. UNPACKING AND ASSEMBLY	6
4. CONTROLS AND INSTRUMENTS	7
5. OPERATING INSTRUCTIONS	9
5.1 Safety recommendations	9
5.2 Why the safety devices cut in	9
5.3 Preliminary operations before starting work	9
5.4 Using the machine	10
5.5 Using on slopes	13
5.6 Suggestions for maintaining a nice lawn	13
6. MAINTENANCE	14
6.1 Safety recommendations	14
6.2 Routine maintenance	14
6.3 Interventions on the machine	15
7. TROUBLESHOOTING	16
8. ATTACHMENTS ON REQUEST	17

HOW TO READ THE MANUAL

Some paragraphs in the manual contain important information regarding safety and operation and are emphasized in this manner:

NOTE or IMPORTANT

These give details or further information on what has already been said, and aims to prevent damage to the machine.

⚠ WARNING! *Non-observance will result in the risk of injury to oneself or others.*

⚠ DANGER! *Non-observance will result in the risk of serious injury or death to oneself or others.*

The manual describes several machine models that can mainly differ in:

- type of transmission: with mechanical gear-change or with hydrostatic continuous speed adjustment. The models with hydrostatic transmission are identified by the word “HYDRO” on the identification label (see 2.2);
- the inclusion of components or attachments which are not widely available;
- special equipment fitted.

The symbol “” highlights all the differences in usage and is followed by the indication of the version to which it refers.

NOTE *Whenever reference is made to a position on the machine “front”, “back”, “left” or “right” hand side, this is determined from where the operator is seated. (Fig. 1.1)*

IMPORTANT *For all operations regarding the use and maintenance of the engine or the battery not described in this manual, refer to the relevant manuals which form an integral part of all the documentation supplied with the machine.*

1. SAFETY REGULATIONS to be a followed scrupulously

A) TRAINING

- 1) **WARNING!** Read these instructions carefully before operating the machine. Become acquainted with the controls and the proper use of the machine. Learn how to stop the engine quickly. Failure to follow the warnings and instructions may result in fire and/or serious injury. Save all warnings and instructions for future reference.
- 2) Never allow children or persons unfamiliar with these instructions to use the machine. Local laws can restrict the minimum age of the operator.
- 3) Never mow while people, especially children, or pets are nearby.
- 4) Never use the machine if the user is tired or unwell, or has taken medicine, drugs, alcohol or any substances which may slow his reflexes and compromise his judgement.
- 5) Bear in mind that the operator or user is responsible for accidents or unexpected events occurring to other people or their property. It is the user's responsibility to assess the potential risk of the area where work is to be carried out, and to take all the necessary precautions to ensure his own safety and that of others, particularly on slopes or rough, slippery and unstable ground.
- 6) If the machine is sold or lent to others, make sure that the operator looks over the user instructions contained in this manual.
- 7) Do not allow children or other passengers to ride on the machine as they could fall off and injure themselves or compromise safe driving by the operator.

8) The machine operator must follow the driving instructions carefully and, in particular:

- Avoid distractions and maintain concentration whilst working;
- Bear in mind that control of a machine sliding on a slope will not be regained by the application of the brake. The main reasons for loss of control are:
 - Insufficient wheel grip;
 - Excessive speed;
 - Inadequate braking;
 - Type of machine unsuitable for its task;
 - Lack of awareness of the effect of ground conditions, especially slopes;
 - Incorrect use as a towing machine.

9) The machine is supplied with a series of micro-switches and safety devices which must never be tampered with or removed; this will invalidate the warranty and relieve the manufacturer from all responsibility. Always check that the safety devices are working properly before using the machine.

B) PRELIMINARY OPERATIONS

1) While using the machine, always wear anti-slip and resistant work footwear and long pants. Do not operate the machine when barefoot or wearing open sandals. Avoid wearing chains, bracelets, clothing that is loose fitting or has hanging cords or ties. Tie hair back if it is long. Always wear protective earplugs.

2) Thoroughly inspect the entire work area and remove anything that could be thrown by the machine or damage the cutting-means assembly or engine (stones, branches, iron wire, bones, etc.).

3) **WARNING: DANGER!** Petrol is highly flammable.

- Store the fuel in special containers;
 - add fuel, using a funnel, only outdoors; do not smoke during this operation and each time fuel is handled;
 - Top-up with fuel before igniting the engine; never remove the tank cap or add fuel while the engine is running or when it is hot;
 - if you have spilled some fuel, do not attempt to ignite the engine but move the machine away from the area of spillage and avoid creating any source of ignition until the fuel has evaporated and fuel vapours have dissipated;
 - Always put the tank and fuel container caps back on and tighten well;
- 4) Replace faulty silencers.

5) Before using the machine, check its general condition and in particular:
the appearance of the cutting means, and check that the screws and cutting-means assembly are not worn or damaged. Replace the entire cutting means and all damaged or worn screws

to preserve balance. Any repairs must be done at a specialised centre.

6) Check the battery status regularly, and replace it if there is any damage to the casing, cover or terminals.

7) Before starting work, always fit the exit guards (grass catcher, side discharge guard or rear discharge guard).

C) DURING USE

1) Do not operate the engine in a confined space where dangerous carbon monoxide fumes can develop. All ignition operations have to be effected in an open or well-ventilated area. Always remember that exhaust fumes are toxic.

2) Work only in daylight or with good artificial light in good visibility conditions. Keep persons, children and animals away from the working area.

3) If possible, avoid mowing wet grass. Avoid working in the rain and when there is a risk of a thunderstorm risk. Do not use the machine in bad weather conditions, especially when there is risk of lightning.

4) Before igniting the engine, disengage the cutting means or the power socket and put the gear in neutral.

5) Pay special attention when approaching obstacles that could compromise visibility.

6) Engage the parking brake when parking the machine.

7) The machine must not be used on slopes of over 10° (17%), regardless of the mowing direction.

8) Remember there is no such thing as a “safe” slope. Driving on grass slopes requires particular care. To prevent overturning or loss of control over the machine:

- Do not stop or start suddenly when going up or downhill;
- Engage the drive slowly and always keep the machine in transmission, especially when travelling downhill;
- Machine speeds should be kept low on slopes and during tight turns;
- Watch out for humps, hollows and other hidden hazards;
- Never mow across the face of the slope. Lawns on a slope have to be mowed moving up and down and never across them. When changing direction, take great care that the wheels facing the slope do not hit any obstacles (such as stones, branches, roots, etc.) that may cause the machine to slide sideways, tip over or make you lose control.

Reduce speed before any change of direction on slopes, and always apply the parking brake before leaving the machine at a standstill and unattended.

10) Be very careful near ravines, ditches or embankments. The machine could overturn if a wheel slides over the edge or if the earth gives way.

11) Pay maximum attention when working in reverse gear. Look behind you to make sure there are no obstacles before and during operations in reverse gear.

12) Use care when pulling loads or using heavy equipment:

- Use approved drawbar hitch points only when towing;
- Limit loads to those you can safely control;
- Do not turn sharply. Take care when reversing;
- Use counterweight(s) or wheel weights whenever advised in the instructions manual.

13) Disengage the cutting means or the power socket when crossing areas with no grass, when moving to or from areas that require mowing, and move the cutting-means assembly to its highest position.

14) Pay attention to traffic when using the machine near roads.

15) **WARNING!** The machine has not been approved for use on public roads. It must be used (as indicated by the highway code) in private areas closed to traffic.

16) Never operate the machine with damaged guards or without the grass catcher, side discharge guards or rear discharge guards.

17) Never place your hands and feet near or under rotating parts. Keep away from the discharge opening.

18) Do not leave the machine stationary on high grass with the engine running to avoid the risk of starting a fire.

19) When using the attachments, never direct the opening towards people.

20) Use manufacturer-recommended attachments only.

21) Don't use the machine if the attachments/tools are not installed in their seats.

22) Pay attention when using the grass catcher and attachments that can alter the stability of the machine, especially on slopes.

23) Do not change the engine settings or over-rev the engine.

24) Do not touch the engine parts as they get very hot when running. Danger of burns.

25) Disengage the cutting means or power socket, put in neutral and engage the parking brake, turn off the engine and remove the ignition key (checking that all moving parts are completely stationary):

- Whenever the machine is left unattended or the operator dismounts from the driving seat;
- Before clearing blockages or unclogging the discharge chute;
- Before checking, cleaning or working on the

machine;

- After striking a foreign object. Inspect the machine for damage and make repairs before using it again.

26) Disengage the cutting means or the power socket and switch off the engine (making sure that all moving parts are stationary):

- Before refuelling;
- Whenever you remove or reattach the grass catcher;
- Whenever you remove or reattach the side discharge chute;
- Before adjusting the cutting height, if this operation cannot be performed from the driving seat.

27) Disengage the cutting device or the power socket during transport and whenever it is not in use.

28) Reduce the throttle setting before stopping the engine. Shut off the fuel supply on completing the work, following the instructions in the engine manual.

29) Pay attention to cutting means assemblies with more than one cutting means, as a rotating cutting means can trigger the rotation of the others,

30) **WARNING** – If something breaks or an accident occurs whilst working, turn off the engine immediately and move the machine away to prevent further damage; if an accident occurs with injuries or third parties are injured, carry out the first aid measures most suitable for the situation immediately and contact the medical authorities for any necessary health care. Carefully remove any debris that might cause damage or harm persons or animals should it not be seen.

31) **WARNING** - The noise and vibration levels shown in these instructions are the maximum levels for use of the machine. The use of an unbalanced cutting means, excessive speed of movement, or lack of maintenance have a significant influence on noise emissions and vibrations. Consequently, it is necessary to take preventive steps to eliminate possible damage due to high levels of noise and stress from vibration. Maintain the machine well, wear ear protection devices, and take breaks while working.

D) MAINTENANCE AND STORAGE

1) **WARNING!** - Before cleaning or doing maintenance work, take out the ignition key and read the relevant instructions. Wear proper clothing and protective gloves whenever your hands are at risk.

2) **WARNING!** – Never use the machine with worn or damaged parts. Faulty or worn-out parts must always be replaced and not repaired. Use original spare parts only: the use of non-original and/or incorrectly fitted parts will jeopardize the

safety of the machine, may cause accidents or personal injuries for which the Manufacturer is under no circumstance liable or responsible.

3) Any adjustments or maintenance operations not described in this manual must be carried out by your Dealer or a specialized Service Centre with the necessary knowledge and equipment to ensure that the work is done correctly maintaining the machine's original safety level. Any operations performed in unauthorized centres or by unqualified persons will totally invalidate the Warranty and all obligations and responsibilities of the Manufacturer.

4) After each use, remove the ignition key and check for damage.

5) Keep all nuts, bolts and screws tight to be sure the equipment is in safe working condition. Routine maintenance is essential for safety and for maintaining a high performance level.

6) Check that the cutting means screws are properly tightened on a regular basis.

7) Wear work gloves when handling, disassembling and reassembling all cutting means.

8) Keep the cutting means well balanced during sharpening. All works on the cutting means (disassembly, sharpening, balancing, reassembly and/or replacing) are demanding jobs that require special skills as well as special tools. For safety reasons, these jobs are best carried out at a specialised centre.

9) Check that the brakes work properly on a regular basis. It is vital for brakes to undergo regular maintenance and, where necessary, repair work.

10) Check the side discharge guard, the rear discharge guard, the grass catcher and the intake grille frequently. Replace them if they are damaged.

11) Replace any instruction or warning message stickers, if damaged.

12) When the machine is to be stored or left unattended, lower the cutting-means assembly.

13) Store the machine out of the reach of children.

14) Do not store the machine with fuel in the tank in an area where the fuel vapours could reach an open flame, a spark or a strong heat source.

15) Allow the engine to cool down before storing in any enclosure.

16) To reduce fire hazards, keep the engine, silencer, battery compartment and petrol storage area free of grass, leaves, or excessive grease. Always empty the grass catcher and do not leave containers full of cut grass inside storage areas.

17) To reduce fire hazards, check there are no oil and/or fuel leaks on a regular basis.

18) If the fuel tank has to be emptied, this should be done outdoors once the engine has cooled down.

19) Never leave the keys in the ignition or within reach of children or unauthorised persons. Always remove the ignition key before doing any maintenance.

E) TRANSPORT

1) **WARNING!** - If the machine must be transported on a truck or trailer, use ramps with suitable resistance, width and length. Load the machine with the engine switched off, without a driver and pushed by an adequate number of people. During transport, close the fuel stop-cock (if fitted), lower the cutting-means assembly or attachment, engage the parking brake and fasten the machine securely with ropes or chains to the hauling device.

F) ENVIRONMENTAL PROTECTION

1) Environmental protection should be a priority of considerable importance when using the machine, for the benefit of both social coexistence and the environment in which we live. Try not to cause any disturbance to the surrounding area.

2) Scrupulously comply with local regulations and provisions for the disposal of packaging, oils, petrol, filters, damaged parts or any elements which have a strong impact on the environment; this waste must not be disposed of as normal waste, it must be separated and taken to specified waste disposal centres where the material will be recycled.

3) Scrupulously comply with local regulations for the disposal of waste materials after mowing.

4) At the time of decommissioning, do not pollute the environment with the machine, but hand it over to a disposal centre, in accordance with the local laws in force.

2. GETTING TO KNOW THE MACHINE

2.1 DESCRIPTION OF THE MACHINE AND ITS RANGE OF USE

This machine is a garden tool and precisely a ride-on lawnmower with seated operator.

The machine is equipped with an engine which drives a cutting unit protected by a casing, as well as a transmission unit that moves the machine.

The operator is able to operate the machine and use the main controls, always seated in the operator's position.

The devices fitted on the machine stop the engine and the cutting means within a few seconds, should the operator behave in a manner that does not comply with the necessary safety precautions.

Intended use

This machine was designed and built to cut grass.

The use of special attachments provided for by the Manufacturer as original equipment or which may be purchased separately, allows this work to be done in various operating modes, illustrated in this manual or the instructions that accompany the single attachments.

Likewise, the intended use can be extended to include other functions by applying supplementary attachments (if provided for by the Manufacturer), abiding by the restrictions and conditions indicated in the instructions accompanying the attachment.

User types

This machine is intended for use by consumers, i.e. non-professional operators. The machine is intended for "DIY" use only.

Improper use

Any other usage not in keeping with the above-mentioned ones may be hazardous and harm persons and/or damage things. Examples of improper use may include, but are not limited to:

- transporting people, children or animals on the machine or on a trailer;
- use of the machine for riding over unstable, slippery, icy, stony, rough, marshy ground or puddles that do not allow the consistency of the ground to be assessed;
- using the cutting means on surfaces other than grass.
- use of the machine for leaf or debris collection;

Improper use of the machine will invalidate the warranty, relieve the Manufacturer from all liabilities, and the user will consequently be liable for all and any damage or injury to himself or others.

2.2 IDENTIFICATION LABEL AND MACHINE COMPONENTS (see figures on page ii)

1. Acoustic power level
2. CE conformity marking
3. Year of manufacture
4. Operating engine power and speed
5. Type of machine
6. Serial number
7. Weight in kg
8. Name and address of Manufacturer

9. Type of transmission (if indicated)

10. Article code

The example of the Declaration of Conformity is provided on the penultimate page of the manual.



/---/---/---/---/---/---/

Write the serial number of your machine (6) here.

As soon as you have purchased the machine, do not forget to write the identification numbers (3 - 5 - 6) in the spaces on the last page of the manual.

The machine is composed of a series of main components that have the following functions:

11. **Cutting-means assembly:** this is the casing that houses the rotating cutting means.
12. **Cutting means:** these are what cut the grass; the fins at the ends help convey the cut grass towards the collector channel.
13. **Collector channel:** this is the part connecting the Cutting-means assembly to the grass catcher.
14. **Grass catcher:** as well as collecting the grass cuttings, this is also a safety element that stops any objects drawn up by the cutting devices from being hurled away from the machine.
15. **Side discharge chute (if provided)** prevents any objects collected by the cutting means from being hurled away by the machine.
16. **Engine:** this moves the cutting means and drives the wheels. Its specifications and regulations for use are described in a specific manual.
17. **Battery:** provides the energy for starting the engine. Its specifications and regulations for use are described in a specific manual.
18. **Driving seat:** this is where the machine operator sits. It has a sensor connected to safety devices for detecting the presence of the operator.
19. **Warning and safety labels:** these give reminders on the main regulations for working in safety.

2.3 SAFETY REQUIREMENTS

Your machine should be used with due care and attention. Therefore, labels have been placed on the machine to remind you pictorially of the main precautions to take during use. These labels are to be considered an integral part of

the machine. If a label should fall off or become illegible, contact your Retailer to replace it. Their meaning is explained below.

31. **Warning:** Read the instructions before operating the machine.
32. **Warning:** disconnect the key and read the instructions before carrying out any maintenance or repair work.
33. **Danger!** Ejected objects: Keep bystanders away.
34. **Danger! Machine rollover:** Do not use this machine on slopes greater than 10°.
35. **Danger! Dismemberment:** Make sure that children stay clear of the machine all the time when engine is running.
36. **Danger of cutting yourself:** Cutting means in motion. Do not put hands or feet near or under the opening of the cutting means housing.

NOTE *The images corresponding to the texts in chapters 3 et seq., can be found on pages iii et seq. of this manual.*

3. UNPACKING AND ASSEMBLY

For storage and transport purposes, some components of the machine are not installed in the factory and have to be assembled after unpacking. Follow the instructions below.

IMPORTANT *The machine is supplied without engine oil or fuel. Before starting up the engine, fill with oil and fuel following the instructions given in the engine manual.*

⚠ WARNING! *Unpacking and completing the assembly should be done on a flat and stable surface, with enough space for moving the machine and its packaging, always making use of suitable equipment.*

3.1 UNPACKING

When unpacking the machine, take care to gather all individual parts and fittings, and do not damage the cutting-means assembly when taking the machine off the pallet.

The standard packaging contains:

- the machine;
- dashboard cover;
- steering wheel column caster;
- the steering wheel;
- the seat;
- cutting means engagement control lever extension;
- the grass catcher components;
- the lower part of the back plate;

- “mulching” attachment components (if provided);
- the side discharge chute (if provided);
- equipment to be used to complete assembly of the various machine components (in separate bags for each use);
 - a battery charger (if provided);
 - 2 starter keys;
 - a spare 10 A fuse, to be kept in case of necessity.
- Instructions manual and machine documents.

NOTE *To avoid damaging the cutting-means assembly when getting the machine down from the pallet, take it to the maximum height and be very careful.*

Hydrostatic transmission:

- – To make it easier to get the machine off the pallet and to move it, the rear drive disengagement lever should be put in position «B» (see 4.23).

Disposal of the packaging should be done in accordance with the local regulations in force.

3.2 MOUNTING THE REAR PLATE (Fig. 3.1)

- Use equipment marked “A”.
Apply plates (1) to the two supporting brackets (2) and (3), as shown in the figure.
Screw (4) the two brackets (2) and (3) to the chassis supports, taking care they are in the correct right and left positions.
Mount the lower part (5) of the rear plate and screw (6) it to the lower brackets without tightening the screws completely.

Hydrostatic transmission

- – Make sure the release lever (7) is inserted in the rear plate groove correctly and that it runs freely.

Tighten screws (6).

3.3 FITTING THE DASHBOARD AND STEERING WHEEL (Fig. 3.2)

- Use equipment marked “B”.
Put the machine on a flat surface and straighten the front wheels.
Fit the caster (3) on the steering column (2), making sure the plug (1) is correctly fitted into the caster seat.
Fit the steering column extension (3a) in the hole in the caster (3).

Fit the dashboard cover (5) making sure all fastenings click into their respective housings correctly.

Fit the steering wheel (6) onto the caster (3) with all the spokes directed towards the seat. Fit the steering wheel fastening it with the screws (7a/b/c) supplied, in the indicated order. Fit the steering wheel cover (8) clicking the three fasteners into place.

3.4 FITTING THE SEAT (Fig. 3.3)

- Use equipment marked “C”.
- Fit the seat (1) onto the plate (2) using the screws (3a/b/c).

3.5 ASSEMBLY OF THE CUTTING MEANS ENGAGEMENT CONTROL LEVER EXTENSION (Fig. 3.4)

- Use equipment marked “C”.
- Tighten the knob (1) on the extension (2), then screw the extension (2) onto the end of the lever (3).

3.6 CONNECTING THE BATTERY (Fig. 3.5)

The battery (1) is located under the seat and can be reached by moving the cover (2). Connect the battery connector (3) to the machine connector (4) and arrange the wire (5) so that it is held firmly in place (7).

Using the connector (6), charge the battery following instructions in the booklet (see 6.2.3), then put the cover (2) back.

3.7 ASSEMBLING THE GRASS CATCHER (Fig. 3.6)

- Use equipment marked “D”.
- Fit the grass catcher following sequences illustrated in the figures.

3.8 FITTING THE “MULCHING” ATTACHMENT (if provided) (Fig. 3.7)

- Use equipment marked “E”.
- Fit the handle (1) on the deflector cap (2) using the pin (3) pushing it to the end with a hammer. Insert an end of the spring (4) in the deflector cap (2) opening and fasten it with the pin (5) inserted in the specific deflector cap (2) seat (6).

Insert the other end of the spring (4) in the widest part of the hook (7).
Using a screwdriver, fasten the narrowest part of

the hook (7) to the hole in the handle (1).

4. CONTROLS AND INSTRUMENTS

4.1 STEERING WHEEL (Fig. 4.1 no.1)

Turns the front wheels.

4.2 PARKING BRAKE (Fig. 4.1 no.2)

This lever stops the machine from moving when it has been parked. There are two positions:

- «A» = Brake disengaged
- «B» = Brake engaged

- The brake is applied by pressing the pedal right down (4.11 or 4.21) and moving the lever to position «B». When you take your foot off the pedal it will be blocked by the lever in the lowered position.
- To disengage the parking brake, press the pedal (4.11 or 4.21). The lever will return to position «A».

4.3 CUTTING MEANS ENGAGE AND BRAKE CONTROLS (Fig. 4.1 no.3)

This lever has two positions, as shown on the plate:

-  Position «A» = Cutting means disengaged
-  Position «B» = Cutting means engaged

IMPORTANT *The lever must be operated gently, avoiding rough movements.*

- If you engage the cutting means without taking the necessary safety precautions, the engine shuts down and cannot be restarted (see 5.2).
- In disengaging the cutting means (Pos. «A»), a brake is simultaneously activated which stops their rotation within five seconds.

4.4 CUTTING HEIGHT ADJUSTMENT LEVER (Fig. 4.1 no.4)

This lever has several positions so the cut can be regulated at various heights.

- To go from one position to another, move the lever sideways and put it back in one of the stop notches.

4.5 KEY IGNITION SWITCH (Fig. 4.1 no.5)

This key operated control has three positions:

- «OFF» everything is switched off;
- I «ON» activates all parts;
- 🔌 «START» engages the starter motor.

- On being released at the «START» position, the key will automatically return to «ON».

4.6 THROTTLE LEVER (Fig. 4.1 no.6).

Regulates the engine's r.p.m. The positions are indicated on the plate showing the following symbols:

- 🔧 «CHOKE» ((if provided) cold start
- 🐢 «SLOW» for minimum engine speed
- 🐘 «VELOCE» for maximum engine speed

- The «CHOKE» position (if provided) enriches the mixture so it must only be used for the time necessary for cold starts.
- When moving from one area to another, put the lever in a position between «SLOW» and «FAST».
- When cutting, shift into «FAST».

4.7 REVERSE GEAR CUTTING CONSENT PEDAL (Fig. 4.1 no. 7)

By pressing and holding the pedal down, it is possible to switch to reverse gear with the cutting means engaged without causing the engine to stop.

🔧 Mechanical transmission

4.11 CLUTCH / BRAKE PEDAL (Fig. 4.2 no.11)

This pedal has two functions: during the first part of its travel it acts as a clutch, engaging and disengaging drive to the wheels, and in the second part it acts as a brake on the rear wheels

IMPORTANT *Do not keep the pedal half way between clutch engagement or disengagement, as this can cause overheating and damage the transmission belt.*

NOTE *When the machine is in movement, keep your foot off the pedal.*

4.12 SPEED CHANGE LEVER (Fig. 4.2 no.12)

This lever has six positions for the four forward speeds, the neutral position «N», and reverse «R».

To go from one speed to another, press the pedal (4.11) halfway and shift the lever as shown on the label.

⚠ WARNING! *Forward gear must be engaged when the machine has stopped.*

⚠ WARNING! *Reverse must be engaged when the machine has stopped.*

🔄 Hydrostatic transmission

4.21 BRAKE PEDAL (Fig. 4.3 no.21)

This pedal works the brake on the rear wheels.

4.22 CLUTCH PEDAL (Fig. 4.3 no.22)

This pedal engages drive in the wheels and controls the machine's forward and reverse speed.

- To engage forward gear just press it in the «F» direction with the tip of your foot, noting that increasing the pressure on the pedal progressively increases the speed of the machine.
- Reverse is engaged by pressing the pedal with the heel towards «R».
- The pedal automatically goes into neutral «N» when released.

⚠ WARNING! *Reverse must be engaged when the machine has stopped.*

NOTE *If the drive pedal is used, whether forwards or for reverse, when the parking brake (4.2) is engaged, the engine stops.*

4.23 HYDROSTATIC TRANSMISSION DISENGAGEMENT LEVER (Fig. 4.3 no.23)

This lever has two positions as shown on the label:

- «A» = Transmission engaged: for all uses, when moving and during cutting;
- «B» = Transmission disengaged: this makes it much easier to move the machine by hand, with the engine turned off.



IMPORTANT To avoid damaging the transmission unit, this operation must be carried out only when the engine has stopped with the pedal (4.22) at position «N».

5. OPERATING INSTRUCTIONS

5.1 SAFETY RECOMMENDATIONS

⚠ WARNING! Read the safety operating instructions (see 5.5) if the equipment will mainly be used on sloping land (never over 10 degrees).

IMPORTANT All the references relating to the positions of controls are those described in chapter 4.

5.2 WHY THE SAFETY DEVICES CUT IN

The safety devices work in two ways:

- they prevent the engine from starting if all the safety requirements have not been met;
- by stopping the engine if even just one of the safety requirements is lacking.

a) To start the engine, it is necessary that:

- the transmission is in “neutral”;
- all the cutting means are correctly in place;
- the operator is seated.

b) The engine stops when:

- the operator leaves his seat;
- the grass catcher is lifted when the cutting means are engaged;
- the cutting means is engaged without the grass catcher in place;
- the parking brake is engaged without disengaging the cutting means.
- the drive pedal is activated (see 4.22) with the parking brake on.

5.3 PRELIMINARY OPERATIONS BEFORE STARTING WORK

Before starting to mow, it is necessary to carry out several checks and operations to ensure you can work efficiently and in maximum safety.

5.3.1 Seat adjustment (Fig. 5.1)

To change the seat position, loosen the four fixing bolts (1) and slide it along the slots.

Once you have found the right position, tighten

the four screws (1) thoroughly.

5.3.2 Tyre pressure (Fig. 5.2)

Having the right tyre pressure is the main condition for ensuring that the cutting-means assembly is horizontal and mows evenly.

Unscrew the valve caps and connect a compressed air line with a gauge to the valves and adjust the pressure to the indicated values.

5.3.3 Filling with oil and fuel

NOTE The type of oil and fuel to use is given in the engine manual.

To reach the oil dipstick, turn the seat over and remove the cover underneath.

With the engine off, check the oil level. According to the instructions in the engine manual, this must be between the MIN and MAX marks on the dipstick. Fig. 5.3)

Refuel using a funnel, but do not completely fill the tank. Fig. 5.4).

⚠ DANGER! Refuelling should be carried out in an open or well-ventilated area with engine stopped. Always remember that petrol fumes are inflammable. DO NOT TAKE A NAKED FLAME TO THE TANK'S OPENING IN ORDER TO SEE THE TANK'S CONTENTS AND DO NOT SMOKE WHEN REFUELLING.

IMPORTANT Do not drip petrol onto the plastic parts to avoid ruining them. In the event of accidental leaks, rinse immediately with water. The warranty does not cover for damage to plastic parts of the bodywork or the engine caused by petrol.

5.3.4 Preparing the machine and fitting the exit guards (grass catcher or side discharge chute)

NOTE This machine lets you mow lawns in different ways, according to the fitted attachments. The attachments mentioned here may be part of the original equipment or may be purchased afterwards. Before starting work, prepare the machine based on how the lawn is to be mowed. DO THIS WHEN THE ENGINE IS OFF.

⚠ WARNING! Never use the machine without having fitted the exit guards!

- Preparation for grass cutting and collection in the grass catcher (Fig. 5.5)

Hook on the grass catcher (1) inserting the two connections (2) in the holes on the two supports (3).

• **Preparation for mowing and mulching (Fig. 5.7)**

Make sure that the inside of the cutting-means assembly is sufficiently clean and free of grass and mud deposits that might hinder inserting the deflector cap for mulching.

Move the cutting-means assembly to the maximum height position and insert the mulching attachment (1) on the discharge opening, pushing it down inside the collector channel until it stops.

Fasten the two elastic tie-rods (2) to the two holes on the sides of the collector channel (3). Then put the grass catcher on as indicated above.

• **Preparation for mowing and grass side discharge (Fig. 5.8)**

Lift the safety lever(1) and the side discharge guard (2). Fasten the side discharge chute (3) and lower the guard (2), making sure it stays well fastened to the chute protrusions (3a).

The side discharge chute is properly fitted if the two arrows are aligned (4).

Then put the grass catcher on as indicated above.

5.3.5 Checking machine safety and efficiency

1. Check that the safety devices function as described (see 5.2).
2. Check that the brake is in perfect working order.
3. Do not start mowing if the cutting means vibrate or if you are unsure whether they are sharp enough. Always remember that:
 - A badly sharpened cutting means pulls at the grass and causes the lawn to turn yellow.
 - A loose cutting means causes abnormal vibrations and can be dangerous.

⚠ WARNING! *Do not use the machine if you are unsure whether it is working safely or efficiently. If in doubt, contact your Dealer immediately to make the necessary checks or repairs.*

5.4 USING THE MACHINE

5.4.1 Ignition

To start the engine (Fig. 5.9):

- open the fuel stopcock (1) (if fitted) accessing it from the left rear wheel compartment;
- put the transmission into neutral («N») (see 4.12 or 4.22);
- disengage the cutting means (see 4.3);
- apply the parking brake on sloping ground;
- for a cold start, use the choke (see 4.6);
- if the engine is already warm or without a choke, just put the lever between «SLOW» and «FAST»;
- insert the ignition key and turn to «ON» to make electrical contact, then turn to «START» to start the engine;
- release the ignition key once the engine has started.

After the machine has run for a few seconds, put the accelerator lever on «START» and then on «SLOW».

IMPORTANT *The choke (if provided) must be closed as soon as the engine is running smoothly. Using it when the engine is already warm can foul the spark plugs and cause the engine to run erratically.*

NOTE *If there are engine starting problems, do not insist as you can risk running the battery flat and flooding the engine. Turn the key to the «OFF» position, wait for a few seconds and then repeat the operation. If the malfunction persists, refer to the engine manual and chapter «7» in this manual.*

IMPORTANT *Always bear in mind that the safety devices prevent the engine from starting if safety requirements have not been met (see 5.2). In these cases, once the situation has been corrected, the key must first be turned back to «OFF» before the engine can be restarted.*

5.4.2 Forward gear and riding without mowing

When moving the machine:

- disengage the cutting means;
- bring the cutting-means assembly to the highest position (position «7»);
- put the accelerator control between the «SLOW» and «FAST» positions.

Mechanical transmission

- Push the pedal down as far as possible (see 4.11) and move the gear change lever into 1st gear (see 4.12).
- Keep the pedal pressed down and disengage the parking brake. Slowly release the pedal which will turn from «brake» to «clutch», thus operating the rear wheels (see 4.11).

⚠ WARNING! *The pedal has to be released gradually, as a sudden engagement may cause the vehicle to tip over and the driver to lose control.*

- Gradually reach the desired speed using the throttle and gear lever. To change gear, press the clutch halfway down (see 4.11).

IMPORTANT *Forward gear must only be engaged when the machine has stopped.*

Hydrostatic transmission:

- Disengage the parking brake and release the brake pedal (see 4.21).
- Press the drive pedal (see 4.22) in direction «F» and reach the required speed by progressively increasing pressure on the pedal and moving the accelerator.

⚠ WARNING! *Drive must be engaged as described below (see 4.22) to prevent sudden engagement from causing tipping up and loss of control of the vehicle, particularly on slopes.*

5.4.3 Braking

Mechanical transmission

- To use the brake, press the brake pedal to the floor (see 4.11), after reducing speed using the accelerator so as not to overload the braking system.

Hydrostatic transmission

- First reduce the machine's speed by reducing the engine's r.p.m., and then press the brake pedal (see 4.21) to slow down the machine until it stops.
- The machine already slows down considerably by just releasing the drive pedal.

5.4.4 Reverse

IMPORTANT *Reverse must only be engaged when the machine has stopped.*

IMPORTANT *To proceed in reverse gear with the cutting means engaged, it is necessary to press and hold the consent pedal down (see 4.7) so as not to cause the engine to stop.*

Mechanical transmission

- Press the pedal until the machine stops and then switch into reverse by shifting the lever sideways and into position «R» (see 4.12).
- Gradually release the pedal to engage the clutch and then begin moving in reverse.

Hydrostatic transmission:

- When the machine is stopped, start the reverse movement by pressing the drive pedal in the «R» direction (see 4.22).

5.4.5 Grass cutting

To start cutting:

- move the throttle to «FAST»;
- bring the cutting-means assembly to the highest position;
- let the engine warm up a few minutes before engaging the cutting means;
- engage the cutting means (see 4.3) only on short grass lawns; avoid engaging them on stony ground or when the grass is very high;

IMPORTANT *If the cutting means are engaged when the grass is too high, the engine could suffer a sudden drop of r.p.m. and stop in some cases, or the clutch may be worn.*

- start moving forwards on the grass very slowly and with utmost caution, as already described;
- regulate the cutting height and speed (see 4.4) considering the conditions of the lawn (the height, density and dampness of the grass).

Mechanical transmission

- – High and dense grass – wet lawn: 1st gear
- – Low grass – dry lawn: 2nd 3rd gear

NOTE *The fourth gear is just a transfer gear to be used on the flat.*



Hydrostatic transmission

- Speed can be adjusted according to lawn conditions by gradually and continuously pressing the speed adjustment **pedal** accordingly.

⚠ WARNING! *When cutting on sloping ground, the forward speed must be reduced to ensure safe conditions (see 1A-C7-8-9).*

Whatever the conditions, always reduce the speed if you notice a drop in engine speed – if you travel too fast compared to the amount of grass being cut, you will not be able to mow the grass well.

Disengage the cutting means and raise the cutting-means assembly as high as possible whenever you need to get past an obstacle.

5.4.6 Emptying the grass catcher (Fig. 5.10)

NOTE *The emptying of the grass catcher can only be done with the cutting means disengaged, otherwise the engine stops.*

The grass catcher is full when the grass cuttings remain on the lawn. If you continue mowing with the grass catcher full, it may block the collector channel.

To empty the grass catcher:

- disengage the cutting means (see 4.3);
- lower the engine speed;
- shift into neutral (N) (see 4.12 – Mechanical transmission or 4.22 – Hydrostatic transmission) and stop moving forward;
- engage the parking brake on slopes;
- hold onto the rear handle (1) and tip up the grass catcher to empty it;

5.4.7 Unblocking the collector channel

Cutting very tall or wet grass, particularly at excessively high speed, can clog up the collector channel. If this happens proceed as follows:

- stop forward movement immediately, disengage the cutting means and stop the engine;
- remove the grass catcher;
- remove the grass cuttings; you can reach them from the channel discharge opening.

⚠ WARNING! *This job must only be performed with the engine turned off.*

5.4.8 End of mowing

When you have finished mowing, disengage the cutting means, reduce the engine speed and ride the machine with the cutting-means assembly in the highest position.

5.4.9 End of work

Stop the machine, put the accelerator lever in the «SLOW» position and turn off the engine by putting the ignition key into the «OFF» position. When the engine has stopped, close the fuel stopcock (1) (if fitted). Fig. 5.11)

⚠ WARNING! *To avoid backfire, put the accelerator in the «SLOW» position for 20 seconds before stopping the engine.*

IMPORTANT *To keep the battery charged, do not leave the ignition key in the «ON» position when the engine is not running.*

5.4.10 Cleaning the machine

After each mowing session, clean the outside of the machine, empty the grass catcher and shake it to remove residual grass and earth.

Clean the plastic parts of the body with a damp sponge using water and detergent, taking care not to wet the engine, the electrical parts or the electronic circuit board located under the seat.

IMPORTANT *Never use hose-nozzles or harsh detergents for cleaning the body and engine!*

⚠ WARNING! *Do not let debris and dried grass accumulate in the upper part of the cutting-means assembly in order to maintain maximum machine efficiency and safety levels.*

After each use, clean the cutting-means assembly thoroughly to remove any grass remains or debris.

⚠ WARNING! *Wear eye protection and keep people or animals away from the surrounding area when cleaning the cutting-means assembly.*

- a) When washing the inside of the cutting-means assembly and the collector channel, the machine must be on firm ground:
- prepare the machine according to the operating mode that was used the last time (see 5.3.4);

- connect a water hose to its pipe fitting (1), and run water through it (Fig. 5.12);
- sit in the operator's position;
- lower the cutting-means assembly completely;
- start the engine and stay in neutral;
- engage the cutting means and allow them to run idle for a few minutes.

Remove the grass catcher, the side discharge chute or mulching attachment (if provided), rinse and place them where they can dry quickly.

b) To clean the upper part of the cutting-means assembly:

- lower the cutting-means assembly completely (position «1»);
- blow a jet of compressed air through the right and left guard openings. Fig. 5.13)

5.4.11 Storage and inactivity for long periods

If you intend not to use the machine for a long period (more than 1 month), disconnect the battery cables and follow the instructions in the engine instruction manual.

Fig. 5.14) Close the fuel stopcock (1).

Remove the clamp (2) using pliers, reconnect the tube (3) and empty the tank collecting all the fuel in a suitable container.

Open the tap (1) and start the engine, leaving it running till it stops because all fuel left in the tubes and carburettor has been used up.

Reconnect the tube (3) making sure you position the clamp properly (2).

Put the machine away in a dry, sheltered place and preferably covered with a cloth (see 8.3).

IMPORTANT *The battery must be kept in a cool and dry place. Before a long storage period (more than 1 month), always charge the battery, and then recharge before using again (see 6.2.3).*

The next time the machine is used, check that there are no fuel leaks from the tubes, fuel stopcock or carburettor.

5.5 USING ON SLOPES (Fig. 5.15)

Observe the indicated limits (**max 10° - 17%**).

⚠ WARNING! *Take care when beginning forward movement on sloping ground to prevent the risk of tipping up. Reduce the forward speed before going on a slope, particularly downhill.*

⚠ DANGER! *Never switch to reverse gear*

to decrease speed when going downhill: this could cause loss of control of the machine, especially on slippery ground.

Mechanical transmission

- **⚠ DANGER!** *Never ride the machine on slopes in neutral or with the clutch out!*
- *Always shift into a low gear before leaving the machine at a standstill and unattended.*

Hydrostatic transmission:

- Drive down slopes with your foot off the drive
- pedal (see 4.22) to use the braking effect of
- the hydrostatic transmission when the trans-
- mission is not engaged.

5.6 SUGGESTIONS FOR MAINTAINING A NICE LAWN

1. To keep a lawn green and soft with a good appearance, it should be cut regularly without damaging the grass. A lawn can be composed of different types of grass. If the lawn is cut frequently, grass and roots grow more vigorously, forming a solid grassy bed. If the lawn is cut less frequently, higher grass and weeds start growing (clover and daisies, etc.).
2. It is always better to cut the grass when dry.
3. The cutting means must be in good condition and well sharpened so that the grass is cut straight without a ragged edge that leads to yellowing at the ends.
4. The engine must run at full speed, both to ensure a sharp cut of the grass and to get the necessary thrust to push the cuttings through the collector channel.
5. The frequency of mowing should be in relation to the rate of growth of the grass, which should not be left to grow too much between one cut and the next.
6. During hot and dry periods, the grass should be cut a little higher to prevent the ground from drying out.
7. The best height of the grass on a well-kept lawn is approx. 4-5 cm. and with one mowing, you do not need to remove more than a third of the total height. If the grass is very tall, it should be cut twice in a twenty-four hour period. The first time with the cutting means at maximum cutting height, possibly reducing the cutting width and the second cut at the height desired. Fig. 5.16)
8. The appearance of the lawn will improve if you alternate the cutting in

- both directions. Fig. 5.17)
9. If the collector system tends to get blocked with grass, you should reduce the forward speed as it may be too high for the condition of the grass. If the problem persists, the probable causes are either badly sharpened cutting means or deformed fins.
 10. Be very careful when mowing near bushes or kerbs as these could distort the horizontal position of the cutting-means assembly and damage its edge as well as the cutting means.

6. MAINTENANCE

6.1 SAFETY RECOMMENDATIONS

⚠ WARNING! *You must go to a specialized*

Service Centre or contact your Dealer if the following are malfunctioning:

- **the brake;**
- **the cutting means engage and disengage functions,**
- **switching the drive to forward or reverse gears.**

6.2 ROUTINE MAINTENANCE

The table will help you maintain your machine's safety and performance. It summarises the main interventions to be made and the frequency applicable to each of them.

The boxes at the side are for you to mark the date or number of working hours at which the intervention was made.

Operation		Hours	Completed (Date or Hours)							
1.	MACHINE									
1.1	Cutting means positioning and sharpening check ³⁾	25								
1.2	Replacing cutting means ³⁾	100								
1.3	Transmission belt check ³⁾	25								
1.4	Transmission belt replacement ^{2) 3)}	–								
1.5	Cutting means control belt check ³⁾	25								
1.6	Replacing the cutting means control belt check ^{2) 3)}	–								
1.7	Brake regulation and check ³⁾	25								
1.8	Drive regulation and check ³⁾	25								
1.9	Cutting means engage and brake check ³⁾	25								
1.10	Complete bolt and screw check	25								
1.11	General lubrication ⁴⁾	25								
2.	ENGINE ¹⁾									
2.1	Replacement of the engine oil	...								
2.2	Air filter cleaning and check	...								
2.3	Air filter replacement	...								
2.4	Fuel filter check	...								
2.5	Fuel filter replacement	...								
2.6	Spark plug points cleaning and check	...								
2.7	Replace spark plug	...								

- 1) See the engine manual for the full list and frequency.
- 2) At the first signs of any malfunction, contact your Dealer immediately.
- 3) The operation must be carried out by your Dealer or a specialized Service Centre.
- 4) General lubrication of all joints should also be carried out whenever the machine is to be left unused for a long period.

6.2.1 Engine (Fig. 6.1)

Follow all the instructions in the engine manual. The engine oil is emptied using a syringe (2) (attachment on request) suited for that use, after unscrewing the cap (1). Fit a small pipe (3) of the right size and at least 400mm long on to the syringe (2) ; push the small pipe (3) into the hole completely, then suck all the oil out; please remember that this operation has to be repeated a few times to empty it completely.

6.2.2 Rear axle

This is a sealed single unit that does not require maintenance. It is permanently lubricated and its lubricant does not need changing or topping up.

6.2.3 Battery (Fig. 6.2)

To ensure good performance of the battery it is essential to keep it carefully maintained. The battery must be periodically recharged using the battery-charger provided (if included).

The machine battery must always be fully charged:

- before using the machine for the first time after purchase;
- every 20 starts of the engine;
- before leaving the machine disused for a long period;
- before starting up the machine after a prolonged period of inactivity.

Carefully read and observe the battery recharging instructions in the booklet provided with the battery. Failure in following the procedure or in charging the battery could permanently damage the battery elements.

A flat battery must be recharged as soon as possible.

IMPORTANT *Recharging must be done using a battery charger at constant voltage. Other recharging systems can irreversibly damage the battery.*

The machine comes with a connector (1) for re-charging; this is connected to the corresponding connector for the special maintenance battery-charger supplied (if included) or available on request (see 8.2).

IMPORTANT *This connector must only be used for connection to the maintenance battery-charger indicated by the Manufacturer. For its use:*

- follow the instructions given in the relative instructions manual;
- follow the instructions in the battery manual.

6.3 INTERVENTIONS ON THE MACHINE

6.3.1 Aligning the cutting-means assembly (Fig. 6.3)

The cutting-means assembly should be properly adjusted to obtain an evenly mown lawn. If mowing is uneven, check the tyre pressure.

If this is not sufficient to achieve an even cut, please contact your Dealer to adjust the alignment of the cutting-means assembly.

6.3.2 Replacing the wheels (Fig. 6.4)

Stop the machine on flat ground and put a block under a load-bearing part of the frame on the side that the wheel is to be changed. The wheels are held by a snap ring (1) which can be removed with a screwdriver.

NOTE *If you have to replace one or both rear wheels, make sure that any differences in their external diameter does not exceed 8-10 mm; on the contrary, you must adjust the cutting-means assembly alignment to prevent uneven mowing.*

IMPORTANT *Before remounting the wheel, apply grease to the axle. Put the snap ring (1) and shoulder washer (2) back in place.*

6.3.3 Repairing or replacing tyres

All puncture repairs or replacements will have to be carried out by a tyre repair expert in accordance with the methods for the kind of tyre used.

6.3.4 Replacing a fuse (Fig. 6.5)

The electric system and the electronic circuit board are protected by a fuse. When it blows the machine stops. In this case, remove the cover (1) to reach the fuse (2) next to the battery. The fuse capacity is indicated on the fuse.

IMPORTANT A blown fuse must always be replaced by one of the same type and ampere rating, and never with one of another rating.
If you cannot find out why the fuse has blown, consult a Licensed Service Centre.

6.3.5 Removing, replacing and reassembling of cutting means

⚠ WARNING! Always wear strong protective gloves to handle the cutting means.

⚠ WARNING! Always replace damaged or bent cutting means; never attempt to repair them! ALWAYS USE ORIGINAL CUTTING MEANS!

Only cutting means bearing the code indicated in the table on page ii must be used on this machine.

Given product evolution, the above mentioned cutting means may be replaced in time with others having similar interchangeable and operating safety features.

7. TROUBLESHOOTING

PROBLEM	LIKELY CAUSE	SOLUTION
1. With the key on «START» the starter motor does not run.	Electronic circuit board blocked due to: – flat battery – fuse blown – bad earthing to the engine or the frame – earth connections of the microswitches disconnected – badly earthed starter motor – starting conditions have not been met	Turn the ignition key to «STOP» position and look for the cause of the problem: – recharge the battery (see 6.2.3) – replace the fuse (10 A) (see 6.3.4) – check connections of black earth leads – check connections – check earth connections – check that the conditions allowing the start are met (see 5.2.a)
2. With the key on «START» the starter motor runs but the engine does not start	– faulty fuel supply – faulty ignition	– check the level in the tank (see 5.3.3) – check the fuel filter – check that spark plug cap is securely fitted – check that the electrodes are clean and have the correct gap
3. The engine stops	Electronic circuit board blocked due to: – earth connections of the microswitches disconnected – flat battery – badly connected battery (poor contact) – engine badly earthed	Turn the ignition key to «STOP» position and look for the cause of the problem: – check connections – recharge the battery (see 6.2.3) – check connections (see 3.5) – check engine earth connection
4. Starting is difficult or the engine runs erratically	– fault in carburetion	– clean or replace the air filter – flush out the float chamber – empty the fuel tank and refill with fresh fuel – check and replace the fuel filter if necessary
5. Weak engine performance during cutting	– forward speed too high in relation to cutting height	– reduce the forward speed and/or raise the cutting height (see 4.4)
6. The engine switches off when the cutting device is engaged	– the movement of the lever used to engage the cutting means is too brusque – you are not ready to engage the cutting means	– do it more slowly – check that the safety requirements are met (see 5.2.b)

PROBLEM	LIKELY CAUSE	SOLUTION
7. Uneven mowing and poor grass collection	– cutting-means assembly is not parallel to the ground – inefficient cutting means; – forward speed too high compared to height of grass – collector channel is blocked – cutting-means assembly is full of grass	– check the tyre pressure (see 5.3.2) – reinstate the alignment of the cutting-means assembly in relation to the ground (see 6.3.1) – contact your dealer – reduce the forward speed and/or raise the cutting-means assembly (see 5.4.5) – wait for the grass to dry – remove the grass catcher and empty the collector channel (see 5.4.7) – clean the cutting-means assembly (see 5.4.10)
8. Unusual vibrations while working	– the cutting means are unbalanced – the cutting means are loose – loose bolts and screws	– contact your dealer – contact your dealer – check and tighten all the engine and frame bolts
9. The cutting means do not engage or do not stop promptly when they are disengaged	– problems with engagement mechanism	– contact your dealer
10. Uncertain or ineffective braking	– the brake is not adjusted correctly	– contact your dealer
11. Erratic forward movement, poor drive when going uphill or if the machine has a tendency to rear up	– problems with the belt or the engagement device	– contact your dealer
12. With the engine running, the machine does not move when the drive pedal is pressed (hydrostatic transmission)	– release lever in position «B»	– put into position «A» (see 4.23).

If problems persist after having performed the above operations, contact your dealer.

⚠ WARNING! *Do not take on complicated repair work without the necessary equipment and technical knowledge. The guarantee is automatically revoked and the manufacturer declines all responsibility for any poorly effected repairs.*

8. ATTACHMENTS ON REQUEST

8.1 “MULCHING” KIT (Fig. 8.1 no.41)

It chops the grass cuttings finely and leaves them on the lawn, instead of collecting them in the grass catcher.

8.2 MAINTENANCE BATTERY CHARGER (if included) (Fig. 8.1 no.42)

This keeps the battery in good working order when the machine is in storage, guaranteeing an optimum level of charge and longer battery life.

8.3 CLOTH COVER (Fig. 8.1 no.43)

Protects the machine from dust when not in use.

DICHIARAZIONE CE DI CONFORMITÀ (Inclusione Obbligatoria)
(Direttiva Macchine 2006/42/CE, Allegato II, parte A)

1. La Dichiarazione CE di Conformità è stata redatta da: **ST. S.p.A. - Via del Lavoro, 6 - 31033 Castelfranco Veneto (TV) - Italy**
2. Dichiaro sotto la propria responsabilità, che la macchina: **Torceda con combustore a bordo scudo / foglio erlen**

- a) Tipo / Modello Base:
b) Descrizione di costruzione:
c) Modifiche:

MJ 88

- d) Motore: a scoppio

3. ☒ Contiene altre specifiche delle direttive:

- MD: 2006/42/CE
e) Ente Certificatore: /
f) Emessa CE nel tipo: /
- DMD: 2006/42/CE, ANNEX VI - 2006/55/CE
D. Lgs. 252/2002, ANNEX VI, proc. 1 (Italy)
e) Ente Certificatore:

MD 157-TUV Rheinland LEA Produkt GmbH
Tiefenbach 2, 50461 Mönchengladbach - Germany

- EMC: 2014/53/EU
- RoHS: 1: 2011/65/EU - 2019/65/EU

4. Riferimento alle Norme armonizzate:

EN ISO 5395-1:2013+A2:2018 EN 55012-2007/A1:2009
EN ISO 5395-3:2013+A1:2017+A2:2018 EN ISO 14982:2005
EN 55011:2012

- a) Livello di protezione sonora misurato
b) Livello di protezione sonora garantito
c) Ampiezza di foglio

98 dB(A)
98 dB(A)
GG cm

- d) Persona autorizzata a compilare il Fascicolo Tecnico:

ST. S.p.A.
Via del Lavoro, 6
31033 Castelfranco Veneto (TV) - Italia

- e) Castelfranco V.le, 13.03.2019

Senior VP Product Technical Division
Maurizio Tordini



IT • Il contenuto e le immagini del presente manuale d'uso sono stati realizzati per conto di ST. S.p.A. e sono tutelati da diritto d'autore – E' vietata ogni riproduzione o alterazione anche parziale non autorizzata del documento.

BG • Съдържанието и изображенията в настоящото ръководство са извършени за ST. S.p.A. и са защитени с авторски права – Забранява се всяко неоторизирано възпроизвеждане или промяна, дори и отчасти на документа.

BS • Sadržaj i slike iz ovog korisničkog priručnika napravljeni su isključivo za ST. S.p.A. i zaštićeni su autorskim pravima – zabranjena je svaka neovlaštena reprodukcija ili izmjena dokumenta, djelomično ili u potpunosti.

CS • Obsah a obrázky v tomto návodu k použití byly zpracovány jménem společnosti ST. S.p.A. a jsou chráněny autorským právem – Reprodukce či nepovolené pozměňování tohoto dokumentu, a to i částečně, je zakázáno.

DA • Indhold og illustrationer i denne vejledning er blevet skabt på vegne af ST. S.p.A. og er beskyttet af ophavsret – Enhver gengivelse eller ændring, også delvis, af dokumentet uden autorisation hertil er forbudt.

DE • Inhalt und Bilder dieser Bedienungsanleitung wurden im Namen von ST. S.p.A. erstellt und sind urheberrechtlich geschützt – Jede nicht genehmigte Vervielfältigung oder Veränderung, auch auszugsweise, dieses Dokuments ist verboten.

EL • Το περιεχόμενο και οι εικόνες στο παρόν εγχειρίδιο χρήσης δημιουργήθηκαν για λογαριασμό της εταιρείας ST. S.p.A. και προστατεύονται από πνευματικά δικαιώματα – Απαγορεύεται οποιαδήποτε αναπαραγωγή ή τροποποίηση, έστω και μερική, του εγγράφου χωρίς έγκριση.

EN • The content and images in this User Manual were produced expressly for ST. S.p.A. and are protected by copyright – any unauthorized reproduction or modification to the document, either partially or in full, is prohibited.

ES • El contenido y las imágenes del presente manual de uso han sido creados por ST. S.p.A. y están protegidos por los derechos de autor – Se prohíbe toda reproducción o modificación, incluso parcial, no autorizada del documento.

ET • Käesoleva kasutusjuhendi sisu ja kujutised on toodetud konkreetselt ettevõttele ST. S.p.A. ja neile rakendub autorikaitse seadus – dokumendi igasugune osaline või täielik ilma loata reprodutseerimine või muutmine on keelatud.

FI • Tämän käyttöoppaan sisältö ja kuvat on valmistettu ST. S.p.A. -yhtiön toimesta ja niitä suojaa tekijänoikeuslaki. – Asiakirjan kaikenlainen kopioiminen tai muuttaminen, osittainkin, on kielletty ilman erityistä lupaa.

FR • Le contenu et les images du présent manuel d'utilisation ont été réalisés pour le compte de ST. S.p.A. et sont protégés par un droit d'auteur – Toute reproduction ou modification non autorisée, même partielle, du document, est interdite.

HR • Sadržaj i slike u ovom priručniku za uporabu izrađeni su za tvrtku ST. S.p.A. te su obuhvaćeni autorskim pravima – Zabranjuje se neovlašteno umnožavanje ili prilagodba, djelomična ili u cijelosti, ovog dokumenta.

HU • Ennek a használati útmutatónak a tartalma és a benne szereplő képek kizárólag a ST. S.p.A. számára készültek és szerzői joggal védettek – tilos a dokumentum bármely részének vagy egészének engedély nélküli sokszorosítása és módosítása.

LT • Šio naudotojo vadovo turinys ir paveikslėliai skirti tik „ST. S.p.A.“ ir yra saugomi autorių teisėmis – dokumentą atgaminti ar modifikuoti, visiškai arba iš dalies, yra draudžiama.

LV • Šis lietotāja rokasgrāmats saturs un attēli ir veidoti tikai ST. S.p.A. un ir aizsargāti ar autortiesībām. Jebkāda dokumenta vai tā daļas prettiesiska kopēšana vai pārveide ir stingri aizliegta.

MK • Содржината и сликите во Упатството за корисникот се подготвени исклучиво за ST. S.p.A. и се заштитени со авторски права – забрането е секое делумно или целосно неовластено репродуцирање или измена на документот.

NL • De inhoud en de afbeeldingen van deze gebruikshandleiding werden gerealiseerd voor rekening van ST. S.p.A. en zijn beschermd door het auteursrecht – Elke niet-geautoriseerde reproductie of wijziging, ook gedeeltelijke, van het document is verboden.

NO • Innholdet og bildene i denne brukerveiledningen er utført på oppdrag fra ST. S.p.A. og er beskyttet ved opphavsrett – Enhver gjengivelse eller endring, selv kun delvis, er forbudt.

PL • Treść oraz ilustracje zawarte w niniejszej instrukcji obsługi powstały na zlecenie spółki ST. S.p.A. i są chronione prawami autorskimi – Zabrania się wszelkiego kopiowania bądź modyfikowania, także częściowego, niniejszego dokumentu bez uzyskania stosownej zgody.

PT • As imagens e os conteúdos contidos no presente Manual do Utilizador foram expressamente criados para uso exclusivo da ST. S.p.A., encontrando-se protegidos por direitos de autor. Qualquer tipo de reprodução ou alteração, parcial ou integral, não autorizadas deste Manual estão expressamente proibidas.

RO • Conținutul și imaginile din manualul de utilizare de față au fost realizate în numele ST. S.p.A. și sunt protejate de drepturi de autor – Este interzisă orice reproducere sau modificare chiar și parțială neautorizată a documentului.

RU • Тесты и изображения, содержащиеся в настоящем руководстве, были созданы в интересах ST. S.p.A. и защищены авторскими правами – Любое несанкционированное воспроизведение или изменение документа запрещено.

SK • Obsah a obrázky v tomto návode na používanie boli spracované menom spoločnosti ST. S.p.A. a sú chránené autorským právom – Reprodukcie či nepovolené pozmeňovanie tohto dokumentu, a to aj čiastočné, je zakázané.

SL • Vsebine in slike v tem uporabniškem priručniku so izdelane za podjetje ST. S.p.A. in so zaščiten z avtorskimi pravicami – vsakršno nepooblaščenno razmnoževanje ali spreminjanje dokumenta, v celoti ali delno, je prepovedano.

SR • Sadržaj i slike ovog priručnika za upotrebu su napravljeni u ime ST. S.p.A. i zaštićeni su autorskim pravima – Zabranjena je svaka potpuna ili delimična reprodukcija ili izmena dokumenta bez odobrenja.

SV • Innehållet och bilderna i denna användarhandbok har framställts för ST. S.p.A. och skyddas av upphovsrätt – all form av reproduktion eller ändring, även partiell, som inte auktoriserats är förbjuden.

TR • Bu Kullanıcı Kılavuzundaki içerik ve resimler açıkça ST. S.p.A. için üretilmiştir ve telif hakkı ile korunmaktadır – dokümanın izinsiz olarak tamamen ya da kısmen herhangi bir şekilde çoğaltılması ya da değiştirilmesi yasaktır.



.....		 L_{WA} dB
Type:		
Art.N		CE
..... -s/n		

ST. S.p.A.

Via del Lavoro, 6

31033 Castelfranco Veneto (TV) ITALY